


Current Topics in Data Science and Al

Self-Supervised

Denoising in Microscopy

Deep Learning for Denoising



Low exposure:

- Low photo toxicity
- Low bleaching
- Noisy

High exposure:

- Strong photo toxicity (8)
- Strong bleaching 8
- Less noise 🙂

Self-Supervised Noise2 Void

You only need individual noisy images!

Noise2Void – Assumptions

p(x,y)=p(x)p(y)



Noisy image (x) aka observation

independent


additive noise

$$p(\mathbf{n}|\mathbf{s}) = p(n_1 \dots n_m|\mathbf{s}) = \prod_{i=1}^m p(n_i|s_i)$$


$$n_i \perp n_i \mid s_i$$

$$p(\mathbf{x}|\mathbf{s}) = p(x_1 \dots x_m|\mathbf{s}) = \prod_{i=1}^m p(x_i|s_i)$$
$$x_i \perp \!\!\! \perp x_i \mid s_i$$


can estimate central signal




Noise2Void




Noise2Void - Blind Spot Network





Noise2Void - Blind Spot Implementation






Noise2Void - Blind Spot Implementation







Target

Noise2Void - Results





Noise2Void - Why does it work?





Supervised:

Minimising
$$\sum_{i} (s_i - \hat{s}_i)^2 \longrightarrow \hat{s}_i \approx \mathbb{E}_{p(s_i|x)}[s_i]$$

N2V:
$$\hat{s}_i$$
Minimising $\sum_i (x_i - \hat{s}_i)^2 \longrightarrow \hat{s}_i \approx \mathbb{E}_{p(x_i | \tilde{x}_i)}[x_i]$

$$= \mathbb{E}_{p(s_i|\widetilde{x}_i)}[s_i]$$

Why it works:

$$\mathbb{E}_{p(x_{i}|\widetilde{\boldsymbol{x}}_{i})}[x_{i}]$$

$$= \int x_{i} p(x_{i}|\widetilde{\boldsymbol{x}}_{i}) dx_{i}$$
Marginalisation
$$= \int x_{i} \int p(x_{i}, s_{i}|\widetilde{\boldsymbol{x}}_{i}) ds_{i} dx_{i}$$
Product rule
$$= \int x_{i} \int p(x_{i}|s_{i}, \widetilde{\boldsymbol{x}}_{i}) p(s_{i}|\widetilde{\boldsymbol{x}}_{i}) ds_{i} dx_{i}$$

$$= \int \int x_{i} p(x_{i}|s_{i}, \widetilde{\boldsymbol{x}}_{i}) p(s_{i}|\widetilde{\boldsymbol{x}}_{i}) ds_{i} dx_{i}$$

$$= \int \int x_{i} p(x_{i}|s_{i}, \widetilde{\boldsymbol{x}}_{i}) p(s_{i}|\widetilde{\boldsymbol{x}}_{i}) dx_{i} ds_{i}$$

$$= \int \int x_{i} p(x_{i}|s_{i}, \widetilde{\boldsymbol{x}}_{i}) p(s_{i}|\widetilde{\boldsymbol{x}}_{i}) dx_{i} ds_{i}$$

$$= \int p(s_{i}|\widetilde{\boldsymbol{x}}_{i}) \int x_{i} p(x_{i}|s_{i}, \widetilde{\boldsymbol{x}}_{i}) dx_{i} ds_{i}$$


$$= \int p(s_i | \widetilde{\boldsymbol{x}}_i) \int x_i \, p(x_i | s_i, \widetilde{\boldsymbol{x}}_i) \, dx_i \, ds_i$$

$$= \int p(s_i | \widetilde{\boldsymbol{x}}_i) \int x_i \, p(x_i | s_i) \, dx_i \, ds_i$$


$$= \int p(s_i | \widetilde{\boldsymbol{x}}_i) \, \mathbb{E}_{p(x_i | s_i)}[x_i] \, ds_i$$

$$= \int p(s_i | \widetilde{\boldsymbol{x}}_i) s_i \, ds_i$$
Expected value
$$= \int p(s_i | \widetilde{\boldsymbol{x}}_i) s_i \, ds_i$$
Expected value
$$= \mathbb{E}_{p(s_i | \widetilde{\boldsymbol{x}}_i)}[s_i]$$

Noise2Void - results




Input (max projection)




Noise2Void (max projection)

Data by Romina Piscitel, Eaton lab at MPI-CBG


Noise2Void - limitations



Input (max projection)




Noise2Void (max projection)




Room for Improvement


Traditional (supervised)




PSNR:36.71



Noise2Void




PSNR:35.73



 $\mathbb{E}_{p(s_i|\widetilde{x}_i)}[s_i]$

Probabilistic N2V



PSNR:36.51

Idea:

Predict prob. distributions



Include probabilistic noise model

$$\mathbb{E}_{p(S_i|\boldsymbol{x})}[S_i]$$



Summary

- Self-Supervised denoising (Noise2Void):
 - Works with unpaired data.
 - Assumptions about the noise.
 - Predict each pixel value from its surroundings.
 - Will remove unstructured noise.
 - Will reveal structured noise.
 - PSNR below supervised training.
- Probabilistic Noise2Void:
 - Improved PSNR
 - Reintroduces information from blind spot.
 - Requires noise model.